

## Quick installation steps


Read the **Full Fitting Instructions** before starting installation

1. Check the decking inserts fit your grooved decking.
2. Clean and dry your deck (see full fitting instructions below)
3. Ensure your inserts are clean and have been stored indoors.
4. Pump in a thick line of adhesive and push down insert.
5. Leave to set for 24 hours before walking on.

We recommend 2 inserts per standard width 145mm deck board, to ensure good anti slip coverage. If you walk along the length of the grooves (not across the grooves) we recommend 3 inserts per standard width 145mm deck board. This is to ensure you cannot walk down the middle of the deck board and NOT step on an insert.

## Full fitting instructions – Domestic applications

### 1. How to check your inserts fit your decking?



Drop a sample length of anti slip insert into the grooves of your decking.

If the wings of the insert sit above the top of the decking, this means its NOT a fit.

If the insert rocks from side to side, it means the wings are NOT flat on the deck. This rocking will eventually have a negative impact on the adhesive bond and it will fail. A raised insert could also become a trip hazard. A rocking insert will also cause any screw fittings to eventually fail.

### 2. Cleaning your deck before installation

When using any adhesive, you must remove the dirt and grease from the surfaces you want to bond before you apply the adhesive. If your deck is dirty / covered in algae or grease, the adhesive will not work as it will bond to the dirt / grease and not the timber, which will mean the anti slip insert will not be fully secure.

Be aware oils from the timber and dirt / grease in the grooves may not be easily visible. We therefore highly recommend you first clean your deck with a good quality deck cleaner before using the recommended adhesive GB Pro (available on our website, please see following page for details), to install your inserts. There are many good deck cleaning products on the market. We recommend you follow the instructions provided by the manufacturers.

Deck cleaning products you may wish to consider include ...

Clearway for paths, patios and decking / Owatol NetTrol / Ronseal High Performance Deck Cleaner

#### Cleaning your deck + extra considerations

- Some deck cleaning solutions can be fairly toxic for a period, so do look on the packaging to see if there are any warnings in relation to plants, pets or kids.
- Whatever the deck cleaning instructions, we would recommend prior to using the deck cleaner to give your decking a good brush, even if the cleaning instructions suggest there is no need.
- After using the deck cleaner, make sure you have washed off the deck before applying the adhesive. The adhesive bond could fail due to contaminants from the cleaner itself.
- Brush off any sitting water, to make sure you get the best possible bond between the inserts and your timber deck.
- Install your inserts within 24 hours of cleaning your deck. If you leave it too long natural oils and dirt may start to build up in your deck and have a negative impact on the adhesive bond

# Fitting Instructions Anti Slip Decking Inserts



### 3. Prepare your anti slip decking inserts + are they clean?

Make sure that the inserts have been stored indoors, ideally in its original packaging. This will keep it clean prior to installation. If you suspect the insert is dirty from being left outside, wipe the underside down with a clean dry cloth.

### 4. Pump in a generous line of adhesive

Pump a generous line of GB Pro adhesive or equivalent into a clean and dry decking groove the full length of the insert. A generous line of adhesive means filling the groove to within 2 -3 mm of the top of the decking board / groove to allow the adhesive to cover the whole underside of the insert when pushed down.

### 5. Drop in the Insert

Drop in and push down the insert until the wings of the insert touch the surface of the deck. Glue and drop in 1 x insert at a time. DO NOT be tempted to pump in several metres of adhesive before going back to drop in the insert. DO NOT leave the adhesive for longer than 20 seconds before dropping in the insert.

### 6. Wipe off any excess adhesive from the decking

When you push down the insert it is likely that the adhesive will be pushed up the sides and spill over onto the deck. Use a cloth to wipe away the excess immediately to avoid having to cut away later.

### 7. Be aware of uneven decking and decking joins

If your decking is uneven, particularly where one deck board ends and another one starts, you may need to consider installation using both adhesive and screws – but only if the decking is not level. Uneven decking will put extra force on the insert and may cause it to rock and eventually cause the adhesive bond to fail. Cutting the insert at the point of uneven joins will help stop the insert moving. For more information on installing with screws, see the additional fitting instructions below.

### 8. Leave adhesive for 24 hours to cure

DO NOT walk on during the first 24 hours. Leave for longer to cure if the outside temperature is below 5 degrees centigrade.

### Cutting guide

Inserts can be cut to length with an angle grinder, using a metal cutting disc or diamond blade. You can use a hacksaw but the blade will blunt easily.

### Installation with adhesive and screws- Commercial, Public Access + High Traffic Areas

In high footfall /commercial areas or when using on uneven decking, you can install using adhesive and screws. You will have to predrill the holes, insert screws are torx head screws and will need a standard torx T10 drive bit / adapter to screw in. Set your drill / driver to the lowest torque setting possible to avoid over tightening and damaging the insert. DO NOT use an impact driver or hammer setting.

You will need a min of 4 screws per 1.0m of insert. Start by screwing in the 2 most central screws and work outwards to avoid bowing of the insert.

- The first screw to be approx 315mm in from the left end.
- The second screw approx 315mm in from the right end.
- The last 2 screws approx 25mm from each end.
- Place extra screws in any area of uneven decking to ensure the insert is pulled down tight to the decking.

### Drilling

If you want to use screws you must first install with adhesive and then drill your own screw holes using a 3mm Bosch Multi Use / Multi Purpose or similar Screw Bit. DO NOT use an impact driver or hammer setting.

We recommend using GB Pro adhesive bond available on our website...

[https://www.edecks.co.uk/products/8650/30/112/0/GB-Pro-Adhesive-\(310ml\)](https://www.edecks.co.uk/products/8650/30/112/0/GB-Pro-Adhesive-(310ml))



The manufacturers of anti slip decking inserts cannot be held responsible for debonding of the inserts